


REPAIR MANUAL

| MODEL | HOUSE CODE | |
|--|------------|----------|
| OLYMPUS OM-2 | MDE | FIG. 3/8 |
| OLYMPUS OPTICAL CO., LTD. TOKYO, JAPAN | | |


NOTE: WHEN ORDERING FOR SPARE PARTS, PLEASE CLARIFY A MODEL, PARTS NUMBER AND QUANTITY.



REPAIR MANUAL

| | | |
|--|------------|----------|
| MODEL | HOUSE CODE | FIG. 4/8 |
| OLYMPUS OM-2 | MDE | |
| OLYMPUS OPTICAL CO., LTD. TOKYO, JAPAN | | |


NOTE: WHEN ORDERING FOR SPARE PARTS, PLEASE CLARIFY A MODEL, PARTS NUMBER AND QUANTITY.



REPAIR MANUAL

| | | |
|--|------------|----------|
| MODEL | HOUSE CODE | FIG. 5/8 |
| OLYMPUS OM-2 | MDE | |
| OLYMPUS OPTICAL CO., LTD. TOKYO, JAPAN | | |


NOTE: WHEN ORDERING FOR SPARE PARTS, PLEASE CLARIFY A MODEL, PARTS NUMBER AND QUANTITY.



REPAIR MANUAL

| MODEL | HOUSE CODE | |
|--|------------|----------|
| OLYMPUS OM-2 | MDE | FIG. 6/B |
| OLYMPUS OPTICAL CO., LTD. TOKYO, JAPAN | | |


NOTE: WHEN ORDERING FOR SPARE PARTS, PLEASE CLARIFY A MODEL, PARTS NUMBER AND QUANTITY.




REPAIR MANUAL

| MODEL | HOUSE CODE | FIG. 7/8 |
|--|------------|----------|
| OLYMPUS OM-2 | MDE | |
| OLYMPUS OPTICAL CO., LTD. TOKYO, JAPAN | | |

NOTE: WHEN ORDERING FOR SPARE PARTS, PLEASE CLARIFY A MODEL, PARTS NUMBER AND QUANTITY.



Shutter Circuit Diagram



REPAIR MANUAL

| | | |
|---------------------------------------|------------|----------|
| MODEL | HOUSE CODE | FIG. 8/8 |
| OLYMPUS OM-2 | MDE | |
| OLYMPUS OPTICAL CO. LTD. TOKYO, JAPAN | | |

NOTE: WHEN ORDERING FOR SPARE PARTS, PLEASE CLARIFY A MODEL, PARTS NUMBER AND QUANTITY