





Electronic Flash TTLAUTO CONNECTOR TYPE3

The TTL Auto Connector Type 3 is required for off-camera TTL Auto flash with the OM-2 (not OM-2N) and T32 (or T20*) with the TTL Auto Cord T. The TTL Auto Connector is screwed into the camera's hot shoe socket in place of the accessory shoe.


* via TTL AUTO Connector T20 if Power Bounce Grip 2 is not used.




- Remove accessory shoe.




- Connect TTL Auto T.



- Attach TTL Auto Connector.



- Remove TTL Auto Cord T.



- Caution
- Use TTL Auto Connector Type 4 for the OM-2N and OM-1N.
 - To remove the TTL Auto Cord T, hold the metal ring (not the cord) tightly and pull.